

# Lab 08 Final Report: Vision-Guided Pick and Place with FSM

---

Authors: Muhammad Aqeel Mehdi & Ehzem

Instructor: Prof. Basit Memon

Lab Assistant: Khuzaima Ali Khan

Task 8.1 - Picking and Placing a Cube (70 points):

The robot must detect a single cube placed randomly in the workspace, compute its coordinates using image processing and depth sensing, and then move to grasp and place it in a predefined target location.

Task 8.2 - Bin It! (30 points):


Ten cubes (in two distinct colors) are randomly scattered. The robot must autonomously detect all cubes of a specific color and move them to the placement zone, earning points for each successfully placed cube.

## Methodology / FSM Description

We implemented a Finite State Machine (FSM) to manage the sequence of operations for pick-and-place. The pipeline includes:

1. Vision Pipeline – RGB image segmentation using LAB thresholding.
2. Perception Module – Converts 2D centroid + depth to 3D camera coordinates.
3. Coordinate Mapping – Uses camera intrinsics and extrinsics to convert to world coordinates.
4. IK & Motion Planning – Computes joint angles using `findJointAngles` and `findOptimalSolution`.
5. Pre-Grasp/Grasp – Robot first moves to a safe pre-grasp pose, then to final grasp pose.
6. Pick & Place – Gripper closes; the object is lifted and moved to the placement location.

The FSM diagram is shown below:



### Step-by-Step Output:

- Detected Centroid: (297.56, 146.76)
- Camera to World Mapping: (x, y, z) = (-2.77, 12.76, 3)
- Pick Joint Angles: [0.2138 -0.9974 -1.7410 -0.4031]
- Pre-Grasp Pose Success: setPosition(...) → Success
- Gripper Command: positionJaw(34) → Confirmed
- Place Location: (-13, -13, 8)
- Place Joint Angles: [-0.7854 1.1683 1.0217 0.9516]
- Gripper Release: Jaw Open

### Limitations and Assumptions

- There was some accuracy problem if we place a cube very closer to the robot like next to the base frame
- Thresholding assumes constant lighting.
- Camera Adjustment should be very precised

### Conclusion


This lab successfully demonstrated a complete pick-and-place pipeline using perception, inverse kinematics, and motion planning. The FSM-based control structure provided clarity and reliability. While hardware and sensing limitations existed, the system achieved its objectives under controlled conditions.

**Code is attached below**


```
% arb = Arbotix('port', 'COM4', 'nservos', 5);  
locations = [0 0 0];  
positions = preception();
```

```
color_intrinsics = struct with fields:  
    width: 1920  
    height: 1080  
    ppx: 950.7278  
    ppy: 533.0599  
    fx: 1.4089e+03  
    fy: 1.4089e+03  
    model: 0  
    coeffs: [0 0 0 0 0]  
depth_intrinsics = struct with fields:  
    width: 640  
    height: 480  
    ppx: 305.3088  
    ppy: 245.3343  
    fx: 474.7335  
    fy: 474.7335  
    model: 2  
    coeffs: [0.1101 0.1787 0.0041 0.0021 -0.0799]  
Tdc = struct with fields:  
    rotation: [1.0000 -0.0033 0.0013 0.0033 1.0000 -0.0025 -0.0013 0.0025 1.0000]  
    translation: [0.0257 0.0013 0.0041]  
Tdc = struct with fields:  
    rotation: [1.0000 -0.0033 0.0013 0.0033 1.0000 -0.0025 -0.0013 0.0025 1.0000]  
    translation: [0.0257 0.0013 0.0041]
```


Colorized depth frame from Intel RealSense SR305




Color RGB frame from Intel RealSense SR305



image





```
object_center = 1x2
    297.5625  146.7656
         0         0
    297.5625  146.7656
x = 2
```

```
topickup = [locations; positions];
for i = 2:size(topickup, 1)
    x = topickup(i, 1)
    y = topickup(i, 2)
    z = topickup(i, 3)
    lab(x, y, z, arb);
end
```

```
x = -2.7715
y = 12.7657
z = 3
```

Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport, visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind, visadevfind, aardvarkfind, and ni845xfind instead.

serPort COM4is in use. Closing it.

Warning: serial will be removed in a future release. Use serialport instead.

If you are using serial with icdevice, continue using serial in this MATLAB release.

```
i = 4
```

```

Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport,
visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind,
visadevfind, aardvarkfind, and ni845xfind instead.
serPort COM4is in use. Closing it.
Warning: serial will be removed in a future release. Use serialport instead.
If you are using serial with icdevice, continue using serial in this MATLAB release.
i = 4
Successfully set jaw
ans =

[]
solutions = 4x4
    0.2138    -2.7385     1.7410    -2.1442
    0.2138    -0.9974    -1.7410    -0.4031
   -2.9278     2.7385    -1.7410     2.1442
   -2.9278     0.9974     1.7410     0.4031
Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport,
visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind,
visadevfind, aardvarkfind, and ni845xfind instead.
serPort COM4is in use. Closing it.
Warning: serial will be removed in a future release. Use serialport instead.
If you are using serial with icdevice, continue using serial in this MATLAB release.
i = 4
currentAngles = 1x5
   -0.0051   -0.0102   -0.0102   -0.0102   -0.0051
pick_jointAngles = 1x4
    0.2138    -0.9974    -1.7410    -0.4031
p_dest = 1x3
   -2.7715   12.7657    8.0000
solutions = 4x4
    0.2138    -2.3990     1.8092    -2.5518
    0.2138    -0.5898    -1.8092    -0.7426
   -2.9278     2.3990    -1.8092     2.5518
   -2.9278     0.5898     1.8092     0.7426
Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport,
visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind,
visadevfind, aardvarkfind, and ni845xfind instead.
serPort COM4is in use. Closing it.
Warning: serial will be removed in a future release. Use serialport instead.
If you are using serial with icdevice, continue using serial in this MATLAB release.
i = 4
currentAngles = 1x5
   -0.0051   -0.0102   -0.0102   -0.0102   -0.0051
Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport,
visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind,
visadevfind, aardvarkfind, and ni845xfind instead.
serPort COM4is in use. Closing it.
Warning: serial will be removed in a future release. Use serialport instead.
If you are using serial with icdevice, continue using serial in this MATLAB release.
i = 4
[INFO] Joint angles sent successfully.
Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport,
visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind,
visadevfind, aardvarkfind, and ni845xfind instead.
serPort COM4is in use. Closing it.
Warning: serial will be removed in a future release. Use serialport instead.
If you are using serial with icdevice, continue using serial in this MATLAB release.
i = 4
[INFO] Joint angles sent successfully.
errorCode = 0
Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport,
visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind,
visadevfind, aardvarkfind, and ni845xfind instead.
serPort COM4is in use. Closing it.

```



Warning: serial will be removed in a future release. Use serialport instead.  
If you are using serial with icdevice, continue using serial in this MATLAB release.

```
i = 4
Successfully set jaw
ans = 0.1278
errorGrip = logical
```

```
1
p_dest = 1x3
    -2.7715    12.7657     8.0000
solutions = 4x4
    0.2138    -2.3990     1.8092    -2.5518
    0.2138    -0.5898    -1.8092    -0.7426
   -2.9278     2.3990    -1.8092     2.5518
   -2.9278     0.5898     1.8092     0.7426
```

Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport, visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind, visadevfind, aardvarkfind, and ni845xfind instead.

serPort COM4is in use. Closing it.

Warning: serial will be removed in a future release. Use serialport instead.  
If you are using serial with icdevice, continue using serial in this MATLAB release.

```
i = 4
currentAngles = 1x5
    0.1994   -0.9664   -1.7181   -0.3988    1.1505
```

Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport, visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind, visadevfind, aardvarkfind, and ni845xfind instead.

serPort COM4is in use. Closing it.

Warning: serial will be removed in a future release. Use serialport instead.  
If you are using serial with icdevice, continue using serial in this MATLAB release.

```
i = 4
[INFO] Joint angles sent successfully.
phi2 = -1.5708
pre_z = 15
```

```
solutions = 4x4
   -3.9270   -1.4913     0.6618   -2.3121
   -3.9270   -0.8295    -0.6618   -1.6503
   -0.7854    1.4913    -0.6618    2.3121
   -0.7854    0.8295     0.6618    1.6503
```

Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport, visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind, visadevfind, aardvarkfind, and ni845xfind instead.

serPort COM4is in use. Closing it.

Warning: serial will be removed in a future release. Use serialport instead.  
If you are using serial with icdevice, continue using serial in this MATLAB release.

```
i = 4
currentAngles = 1x5
    0.1994   -0.6136   -1.8050   -0.7312    1.1505
```

Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport, visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind, visadevfind, aardvarkfind, and ni845xfind instead.

serPort COM4is in use. Closing it.

Warning: serial will be removed in a future release. Use serialport instead.  
If you are using serial with icdevice, continue using serial in this MATLAB release.

```
i = 4
[INFO] Joint angles sent successfully.
solutions = 4x4
```

```
   -3.9270   -2.1900     1.0217   -1.9733
   -3.9270   -1.1683    -1.0217   -0.9516
   -0.7854    2.1900    -1.0217    1.9733
   -0.7854    1.1683     1.0217    0.9516
```

Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport, visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind, visadevfind, aardvarkfind, and ni845xfind instead.

serPort COM4is in use. Closing it.

```

Warning: serial will be removed in a future release. Use serialport instead.
If you are using serial with icdevice, continue using serial in this MATLAB release.
i = 4
currentAngles = 1x5
    -0.7977    0.8744   -0.2863    0.7568    1.1505
place_jointAngles = 1x4
    -0.7854    1.1683    1.0217    0.9516
Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport,
visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind,
visadevfind, aardvarkfind, and ni845xfind instead.
serPort COM4is in use. Closing it.
Warning: serial will be removed in a future release. Use serialport instead.
If you are using serial with icdevice, continue using serial in this MATLAB release.
i = 4
[INFO] Joint angles sent successfully.
Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport,
visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind,
visadevfind, aardvarkfind, and ni845xfind instead.
serPort COM4is in use. Closing it.
Warning: serial will be removed in a future release. Use serialport instead.
If you are using serial with icdevice, continue using serial in this MATLAB release.
i = 4
Successfully set jaw
ans =

[]
p_dest = 1x3
    -13    -13     10
solutions = 4x4
    -3.9270   -1.9068    0.9954   -2.2303
    -3.9270   -0.9113   -0.9954   -1.2348
    -0.7854    1.9068   -0.9954    2.2303
    -0.7854    0.9113    0.9954    1.2348
Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport,
visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind,
visadevfind, aardvarkfind, and ni845xfind instead.
serPort COM4is in use. Closing it.
Warning: serial will be removed in a future release. Use serialport instead.
If you are using serial with icdevice, continue using serial in this MATLAB release.
i = 4
currentAngles = 1x5
    -0.7977    1.1965    1.0431    0.9460   -0.0051
Warning: instrfind will be removed in a future release. For serialport, tcpclient, tcpserver, udpport,
visadev, aardvark, and ni845x objects, use serialportfind, tcpclientfind, tcpserverfind, udpportfind,
visadevfind, aardvarkfind, and ni845xfind instead.
serPort COM4is in use. Closing it.
Warning: serial will be removed in a future release. Use serialport instead.
If you are using serial with icdevice, continue using serial in this MATLAB release.
i = 4
[INFO] Joint angles sent successfully.

```

```

function lab(x, y, z, arb)
    arb = Arbotix('port', 'COM4', 'nservos', 5);
    arb.setpos([0, 0, 0, 0, 0], [50, 50, 50, 50, 50]);
    position = 34;

    success = positionJaw(position);
    % Create an Picking position
    %x = 11.79; y = -17.3; z = 7; phi = -pi/2; % Example target pose
    phi = -pi/2; % Example target pose

```

```

%x = -13; y = 13; z = 3; phi = -pi/2;
%x = 5; y = 0; z = 30; phi = pi/4; % Example target pose(working fine)
% Example initial joint angles

pick_jointAngles = findOptimalSolution( x, y, z, phi)
pickObject([x, y, z], arb);
errorCode = setPosition(pick_jointAngles)
errorGrip = gripObject()
% %After picking the object we need to go to the pre-grasp pose
pickObject([x, y, z], arb);
%now we need to go to the place location
x2=-13;
y2=-13;
z2=5;
phi2=-pi/2
%going to pre-place pose
pre_z=z2+10
jointAnglesUp = findOptimalSolution(x2, y2, pre_z, phi2);
errorUp = setPosition(jointAnglesUp);
place_jointAngles= findOptimalSolution(x2, y2, z2, phi2)
if isempty(place_jointAngles)
    error('No valid IK solution for pick location.');
```

end

```

errorPlace = setPosition(place_jointAngles);
errorRelease = positionJaw(34);
errorPickObj = pickObject([x2, y2, z2] ,arb);
end

function success = positionJaw(position)
    l1 = 8.68;
    l2 = 25.91;
    d_min = 21;
    d_max = 34;
    if position < d_min || position > d_max
        fprintf('Error: Jaw position outside of range');
        success = false;
        return;
    end

    initial_guess = 0;
    options = optimoptions('fsolve', 'Display', 'off');
    theta = fsolve(@(tg) (l1 * cos(tg) + l2 * cos(tg + (asin(-l1 * sin(tg) / l2) -
tg)) - position), initial_guess, options);

    motorLimit = [deg2rad(0), deg2rad(115)];
    if theta < motorLimit(1) || theta > motorLimit(2)
        fprintf('Error: Gripper exceeds limits [-150°, 150°]');
        success = false;
    end
end

```

```

        return;
    end

    arb = Arbotix('port', 'COM4', 'nservos', 5);

    speed = 70; % consistent with lab settings
    arb.setpos(5, theta, speed);

    % Success
    fprintf('Successfully set jaw');

    arb.getpos(5)
    success = true;
end

function solution = findOptimalSolution(x, y, z, phi)
    % Get all IK solutions
    solutions = findJointAngles(x, y, z, phi)
    if y < 0
        % If y is negative, keep only the 4th row
        solutions = solutions(4, :);
    else
        % If y is 0 or positive, keep only the first 3 rows
        solutions = solutions(1:3, :);
    end

    % Filter out non-realizable solutions based on joint limits
    isValid = cellfun(@checkJointLimits, num2cell(solutions, 2)); % Get logical
array
    validSolutions = solutions(isValid, :); % Keep only valid solutions

    % Check if there are valid solutions
    if isempty(validSolutions)
        error('No valid solutions found.');
```

```

    end

    % Get current joint angles
    currentJointAngles = getCurrentPose();

    % Compute the absolute errors for all solutions
    delta = abs(validSolutions - currentJointAngles(1, 1:4));

    % Compute total error for each solution
    totalError = sum(delta, 2);
```

```

    % Find the optimal solution with the minimum error
    [~, idx] = min(totalError);
    solution = validSolutions(idx, :);
end

function theta_solutions = findJointAngles(x, y, z, phi)
% Define link lengths (example values, replace with actual robot parameters)
a2 = 10.6; % Length of link 2
a3 = 10.6; % Length of link 3
d1 = 14.8; % Base height
a4=7.8;
% Compute r and s (wrist center coordinates)
r = sqrt(x^2 + y^2);
s = z - d1;

u=(r-a4*(cos(phi)));
v=(s-a4*(sin(phi)));
% Compute possible theta1 solutions
theta1_1 = mod(atan2(y, x)+pi,2*pi)-pi;
theta1_2 = mod(pi+atan2(y, x)+pi,2*pi)-pi;
% Compute possible theta3 solutions using the cosine rule
cos_theta3 = real((u^2 + v^2 - a2^2 - a3^2) / (2 * a2 * a3));

% if abs(cos_theta3) > 1
% error('No valid solution for theta3 (cosine rule constraint violated)');
%end

theta3_1 = mod((atan2(real(sqrt(1 - cos_theta3.^2)), cos_theta3))+pi,2*pi)-pi; %
First possible theta3

theta3_2 = (mod((atan2(real(-sqrt(1 - cos_theta3.^2)), cos_theta3))+pi,2*pi)-pi);
% Second possible theta3

% Compute possible theta2 solutions
%cosbeta1 = (a3^2 - (u^2+v^2)-(a2^2))/(-2*sqrt(u^2+v^2)*(a2));
% beta1 = acos(cosbeta1);
theta2_1 = mod(atan2(v, u) - atan2(a3 * sin(theta3_1), a2 + a3 * cos(theta3_1))
+pi,2*pi)-pi;
theta2_2 = mod(atan2(v, u) - atan2(a3 * sin(theta3_2), a2 + a3 * cos(theta3_2))
+pi,2*pi)-pi;

%theta2_1 = mod(atan2(v, u) - beta1+pi,2*pi)-pi;
%theta2_2 = mod(atan2(v, u) + beta1+pi,2*pi)-pi;

% Compute theta4 for each solution
theta4_1 = mod((phi - theta2_1 - theta3_1)+pi,2*pi)-pi;
theta4_2 = mod((phi - theta2_2 - theta3_2)+pi,2*pi)-pi;

```

```

% Construct the N x 4 solution matrix
% if y < 0
%     theta_solutions=[theta1_2-pi/2 -pi/2-(theta2_2-pi) -theta3_2 -theta4_2];
% else
%     theta_solutions = [theta1_1-pi/2 -pi/2+theta2_1 theta3_1 theta4_1;
% theta1_1-pi/2 -pi/2+theta2_2 theta3_2 theta4_2;
% theta1_2-pi/2 -pi/2-(theta2_1)-pi -theta3_1 2*pi-theta4_1];
% end
theta_solutions = [theta1_1-pi/2 -pi/2+theta2_1 theta3_1 theta4_1;
theta1_1-pi/2 -pi/2+theta2_2 theta3_2 theta4_2;
theta1_2-pi/2 -pi/2-(theta2_1-pi) -theta3_1 -theta4_1;
theta1_2-pi/2 -pi/2-(theta2_2-pi) -theta3_2 -theta4_2];
% % -----
% theta_solutions = [theta1_1+pi/2 -theta2_1+pi/2 -theta3_1 -theta4_1;
%     theta1_1+pi/2 (-theta2_2)+pi/2 -theta3_2 -theta4_2];
% theta1_2+pi/2 theta2_1-pi/2 -theta3_1 -theta4_1;
% theta1_2+pi/2 theta2_2-pi/2 -theta3_2 -theta4_2; ]
% -----
% theta_solutions = [theta1_1-pi/2 theta2_1+pi/2 theta3_1 theta4_1;
%     theta1_1-pi/2 theta2_2-pi/2 theta3_2 theta4_2;
%     theta1_2-pi/2 theta2_1+pi/2 theta3_1 theta4_1;
%     theta1_2-pi/2 theta2_2-pi/2 theta3_2 theta4_2; ]

% theta_solutions = mod(theta_solutions+pi,2*pi)-pi

end

function isValid = checkJointLimits(theta)
    jointLimits = [-150, 150]; % Joint limits in degrees
    isValid = all(theta >= jointLimits(1) & theta <= jointLimits(2));
end

function currentAngles = getCurrentPose()
    arb = Arbotix('port', 'COM4', 'nervos', 5);
    currentAngles = arb.getpos()
end

function errorCode = setPosition(jointAngles)

    % Constants
    maxAngleDeg = 150; % Maximum servo limit in degrees
    minAngleDeg = -150;

    % Initialize errorCode
    errorCode = 0;
    % Convert radians to degrees for limit check
    anglesDeg = rad2deg(jointAngles);
    % Check limits
    if any(anglesDeg > maxAngleDeg) || any(anglesDeg < minAngleDeg)

```

```

        fprintf('[ERROR] One or more joint angles are outside servo limits
(±150°).\n');
        errorCode = 1;
        return;
    end

    try
        % Send joint angles to servos via Arbotix
        arb = Arbotix('port', 'COM4', 'nservos', 5);
        speed=40;
        arb.setpos(1, jointAngles(1), speed); % Ensure arb object is already
initialized in your workspace
        arb.setpos(2, jointAngles(2), speed);
        arb.setpos(3, jointAngles(3), speed);
        arb.setpos(4, jointAngles(4), speed);
        fprintf('[INFO] Joint angles sent successfully.\n');
    catch
        fprintf('[ERROR] Failed to communicate with Arbotix controller.\n');
        errorCode = 2;
    end
end

function vs = skew(v)
    vs = [0 -v(3) v(2);
          v(3) 0 -v(1);
          -v(2) v(1) 0];
end

function T = exponential(S, theta)
    w_skew = skew(S(1:3));
    exp_w = eye(3) + w_skew*sin(theta) + w_skew^2*(1-cos(theta));
    G = eye(3)*theta + (1-cos(theta))*w_skew+(theta-sin(theta))*w_skew^2;
    T = [exp_w, G*S(4:6);
          zeros(1,3), 1];
end

function Ad_T = adjoint(T)

    R = T(1:3, 1:3);
    p = T(1:3, 4);
    p_hat = skew(p);

    Ad_T = [R, zeros(3,3); p_hat * R, R];
end

function [x, y, z, R] = pincherFK(jointAngles)
    % pincherFK - Computes forward kinematics using POE for Phantom X Pincher
    % INPUT:
    % jointAngles - [theta1, theta2, theta3, theta4] in radians
    % OUTPUT:
    % x, y, z - End-effector position
    % R - Orientation matrix (3x3)
    % Link lengths (in cm)

```

```

l_0 = 10; l_1 = 4.8; l_2 = 10.6; l_3 = 10.6; l_4 = 7.8;
% Zero configuration (home position)
R_home = eye(3); % Identity rotation
p_home = [0; 0; l_0 + l_1 + l_2 + l_3 + l_4];
M = [R_home, p_home; 0 0 0 1];
% Screw Axes
% S1 - Rotation about z-axis at base
omega1 = [0; 0; 1];
q1 = [0; 0; l_0];
v1 = -cross(omega1, q1);
S1 = [omega1; v1];
% S2 - Rotation about x-axis at shoulder
omega2 = [1; 0; 0];
q2 = [0; 0; l_0 + l_1];
v2 = -cross(omega2, q2);
S2 = [omega2; v2];
% S3 - Rotation about x-axis at elbow
q3 = [0; 0; l_0 + l_1 + l_2];
v3 = -cross(omega2, q3);
S3 = [omega2; v3];
% S4 - Rotation about x-axis at wrist
q4 = [0; 0; l_0 + l_1 + l_2 + l_3];
v4 = -cross(omega2, q4);
S4 = [omega2; v4];
% Compute transformation using POE formula
T = exponential(S1, jointAngles(1)) * ...
    exponential(S2, jointAngles(2)) * ...
    exponential(S3, jointAngles(3)) * ...
    exponential(S4, jointAngles(4)) * M;
% Extract position and orientation
position = T(1:3, 4);
R = T(1:3, 1:3);
% Output as separate variables
x = double(position(1));
y = double(position(2));
z = double(position(3));
R=double(R)
x = round(x, 4);
y = round(y, 4);
z = round(z, 4);
R = round(R, 4);
end

function errorCode = pickObject(pose_obj, arb)
    p_dest = pose_obj + [0 0 5] %pre grasp pose 5cm above final pose
    IK = findOptimalSolution(p_dest(1), p_dest(2), p_dest(3), -pi/2); % Manually
    getting destination joint angles for now
    jointAngles = IK(1:4);
    errorCode = setPosition(jointAngles);

```



```

if errorCode ~= 0
    disp("Error.");
    return;
end
end

function success = gripObject()
    multiplier = 96;
    angleIncrement = 0.29;
    success = positionJaw(multiplier*angleIncrement);
end

function positions = preception()
    % Camera intrinsics
    [color_intrinsics, depth_intrinsics] = determineIntrinsics()
    Tdc = determineExtrinsics()
    focalLength = [color_intrinsics.fx color_intrinsics.fy];
    principalPoint = [color_intrinsics.ppx color_intrinsics.ppy];
    imagesize = [double(color_intrinsics.width) double(color_intrinsics.height)];
    [ig, colour_img] = depth_example();

    camerawidth = imagesize(1);
    cameralength = imagesize(2);

    imagewidth = depth_intrinsics.width;
    imagelength = depth_intrinsics.height;

    % Read Image
    imwrite(colour_img, 'pic_Color.png');
    img = imread("pic_Color.png");
    % img2 = img;
    % imshow(img)

    rect = [0 0 640 480];
    img(:, 1:80, :) = 0;
    img(:, 510:640, :) = 0;
    % img(425:480, :, :) = 0;
    % img(1:65, :, :) = 0;
    disp('image')
    imshow(img);
    % Convert to LAB color space
    lab_img = rgb2lab(img);
    [L, a, b] = imsplit(lab_img);
    % Thresholding to isolate object
    Mask = b > 7 | a > 7 ;

```

```

rm2 = bwareaopen(Mask, 300);
rm3 = imfill(rm2, 'holes');
imshow(rm3)
% Enhance Edge Detection
BW = edge(rm3, 'Canny'); % Using Canny edge detector

imshow(BW)

stats2 = regionprops(BW, "BoundingBox");
figure;
imshow(img), hold on;

place_z_stack = 3.2;

centers = [0 0];

for k = 1:length(stats2)
    % Get the BoundingBox
    segmented_img = zeros(size(BW), 'uint8');
    cube_mask = false(size(BW)); % Create an empty mask
    cube_mask(round(stats2(k).BoundingBox(2)):round(stats2(k).BoundingBox(2) +
stats2(k).BoundingBox(4)), ...
    round(stats2(k).BoundingBox(1)):round(stats2(k).BoundingBox(1) +
stats2(k).BoundingBox(3))) = true;
    cubes = cube_mask & BW;
    [H, theta, rho] = hough(cubes);
    P = houghpeaks(H, 5, 'NHoodSize', [55 11]); % Ensure NHoodSize is odd
    lines = houghlines(cubes, theta, rho, P, 'FillGap', 5, 'MinLength', 10);
    max_len = 0;
    for j = 1:length(lines)
        xy = [lines(j).point1; lines(j).point2];
        len = norm(lines(j).point1 - lines(j).point2);
        if len > max_len
            max_len = len;
            xy_long = xy;
        end
    end
    stats = regionprops(cubes, 'Centroid');
    object_center = stats.Centroid % [x, y] format
    centers = [centers; object_center];

    row = round(object_center(2));
    col = round(object_center(1));
    depth = ig(row, col);
end

disp(centers);

positions = [];

```

```

depth = 0.667;
% fx = focalLength(1);
% fy = focalLength(2);
cx = principalPoint(1);
cy = principalPoint(2);

x = length(centers)

for i = 2:length(centers)
    u = centers(i, 1);
    v = centers(i, 2);
    Z_m = depth;

    [X_cm, Y_cm, Z_cm] = pixelToCameraCoords(u, v, Z_m, cx, cy, camerawidth,
cameralength, imagewidth, imagelength);

    pos = [X_cm, Y_cm, Z_cm 1]';

    % some adjustments
    % X_cm = X_cm*20;
    % Y_cm = Y_cm*20;
    Z_cm = 3;
    positions = [positions; X_cm Y_cm Z_cm];
end

```

end

```

function [X_cm, Y_cm, Z_cm] = pixelToCameraCoords(u, v, Z_m, cx, cy, camerawidth,
cameralength, imagewidth, imagelength)
    % pixelToCameraCoords - Converts 2D pixel coordinates and depth to 3D camera
coordinates
    %
    % Inputs:
    %   u, v   - Pixel coordinates
    %   Z_m    - Depth value in meters
    %   fx, fy - Focal lengths in pixels
    %   cx, cy - Principal point (usually image center)
    %
    % Outputs:
    %   X_cm, Y_cm, Z_cm - 3D coordinates in centimeters

    % Compute X, Y in meters

    u0 = (cx) * (640/1920);

```

```

v0 = (cy) * (480/1080);

fx = 320/(tan(deg2rad(34.5)));
fy = 240/(tan(deg2rad(27)));

X = (((u - u0) * Z_m) / fx); %340 %475.1561%360.6;
Y = (((v - v0) * Z_m) / fy); %250 %475.1562%600 %471.03;

% Convert to centimeters
X_cm = X * 100;
Y_cm = -Y * 100;
Z_cm = Z_m * 100;
end

function [color_intrinsics, depth_intrinsics] = determineIntrinsics()
    % Make Pipeline object to manage streaming
    pipe = realsense.pipeline();
    % Start streaming on an arbitrary camera with default settings
    profile = pipe.start();
    % Extract the color stream
    color_stream =
profile.get_stream(realsense.stream.color).as('video_stream_profile');
    depth_stream =
profile.get_stream(realsense.stream.depth).as('video_stream_profile');
    % Get and display the intrinsics
    color_intrinsics = color_stream.get_intrinsics();
    depth_intrinsics = depth_stream.get_intrinsics();
end

function [ig, colour_img] = depth_example()
    %% Create all objects to be used in this file
    % Make Pipeline object to manage streaming
    pipe = realsense.pipeline();
    % Make Colorizer object to prettify depth output
    colorizer = realsense.colorizer();
    % Create a config object to specify configuration of pipeline
    cfg = realsense.config();

    %% Set configuration and start streaming with configuration
    % Stream options are in stream.m; These options tap into the various
    % sensors included in the camera
    streamType = realsense.stream('depth');
    % Data format options are in format.m
    formatType = realsense.format('Distance');
    % Enable default depth
    cfg.enable_stream(streamType, formatType);
    % Enable color stream
    streamType = realsense.stream('color');
    formatType = realsense.format('rgb8');

```

```

cfg.enable_stream(streamType,formatType);

% Start streaming on an arbitrary camera with chosen settings
profile = pipe.start();

%% Acquire and Set device parameters
% Get streaming device's name
dev = profile.get_device();
name = dev.get_info(realsense.camera_info.name);

% Access Depth Sensor
depth_sensor = dev.first('depth_sensor');

% Access RGB Sensor
rgb_sensor = dev.first('roi_sensor');

% Find the mapping from 1 depth unit to meters, i.e. 1 depth unit =
% depth_scaling meters.
depth_scaling = depth_sensor.get_depth_scale();

% Set the control parameters for the depth sensor
% See the option.m file for different settable options that are visible
% to you in the viewer.
optionType = realsense.option('visual_preset');
% Set parameters to the midrange preset. See for options:
% https://intelrealsense.github.io/librealsense/doxygen/
rs__option_8h.html#a07402b9eb861d1defe57dbab8befa3ad
depth_sensor.set_option(optionType,9);

% Set autoexposure for RGB sensor
optionType = realsense.option('enable_auto_exposure');
rgb_sensor.set_option(optionType,1);
optionType = realsense.option('enable_auto_white_balance');
rgb_sensor.set_option(optionType,1);

%% Align the color frame to the depth frame and then get the frames
% Get frames. We discard the first couple to allow
% the camera time to settle
for i = 1:5
    fs = pipe.wait_for_frames();
end

% Alignment
align_to_depth = realsense.align(realsense.stream.depth);
fs = align_to_depth.process(fs);

% Stop streaming
pipe.stop();

%% Depth Post-processing

```

```

% Select depth frame
depth = fs.get_depth_frame();
width = depth.get_width();
height = depth.get_height();

% Decimation filter of magnitude 2
% dec = realsense.decimation_filter(2);
% depth = dec.process(depth);

% Spatial Filtering
% spatial_filter(smooth_alpha, smooth_delta, magnitude, hole_fill)
spatial = realsense.spatial_filter(.5,20,2,0);
depth_p = spatial.process(depth);

% Temporal Filtering
% temporal_filter(smooth_alpha, smooth_delta, persistence_control)
temporal = realsense.temporal_filter(.13,20,3);
depth_p = temporal.process(depth_p);

%% Color Post-processing
% Select color frame
color = fs.get_color_frame();

%% Colorize and display depth frame
% Colorize depth frame
depth_color = colorizer.colorize(depth_p);

% Get actual data and convert into a format imshow can use
% (Color data arrives as [R, G, B, R, G, B, ...] vector)fs
data = depth_color.get_data();
img = permute(reshape(data',
[3,depth_color.get_width(),depth_color.get_height()]),[3 2 1]);

% Display image
imshow(img);
title(sprintf("Colorized depth frame from %s", name));

%% Display RGB frame
% Get actual data and convert into a format imshow can use
% (Color data arrives as [R, G, B, R, G, B, ...] vector)fs
data2 = color.get_data();
im = permute(reshape(data2',[3,color.get_width(),color.get_height()]),[3 2 1]);

% Display image
figure;
imshow(im);
title(sprintf("Color RGB frame from %s", name));

%% Depth frame without colorizing
% Convert depth values to meters

```

```

data3 = depth_scaling * double(depth_p.get_data());

%Arrange data in the right image format
ig = permute(reshape(data3',[width,height]),[2 1]);

% Scale depth values to [0 1] for display
figure;
imshow(mat2gray(ig));
colour_img = im;
end

function Tdc = determineExtrinsics()
    % Make Pipeline object to manage streaming
    pipe = realsense.pipeline();
    % Start streaming on an arbitrary camera with default settings
    profile = pipe.start();
    % Extract the color and depth streams
    color_stream =
profile.get_stream(realsense.stream.color).as('video_stream_profile');
    depth_stream =
profile.get_stream(realsense.stream.depth).as('video_stream_profile');
    % Get and display the intrinsics
    Tdc = depth_stream.get_extrinsics_to(color_stream)
end

```